

End Cap Installation

2 inch metal, 22 gauge clips are used



They are pressed into the foam very two feet making sure that the corner clips are installed two inches from the corner. If necessary, hammer can be used to tap them flush with the edge of the panel. If sections are greater than two feet in length, make sure that there are at least three clips installed.



With the ½ inch (12mm) board side up, screw through the board into the cap using countersinking 1¼ self tapping screws. Cut the end cap to size and screw it into the cap. The finished installation is pictured below. If countersinking screws are not available a drill can be used with a counter sinking bit to quickly allow the screws to countersink.

