

## Window Casing Installation

Assemblies are made with panels butted together.



Panels are cut to be Flush with the edge of the window opening



Window bucks for the top and bottom of the window are cut to the length of the opening and installed using self tapping screws to securely attach them to the frame.



Vertical bucks are then cut to length (window opening minus the thickness of the top and bottom bucks, 1 inch) and installed with self tapping screws.



Flashing, caulking and water barrier details are identical to common window installations.

The result is a window buck that easily allows for window installation which will not rot and can be finished in the inside just like drywall.